

BACnet Protocol Implementation Conformance Statement

Date : May 04, 2017

Vendor Name: Delta Electronics, Inc.

Product Name: CFP2000

Product Model Number: VFD-CFP2000

Applications Software Version: Ver 01.04- yyyyymm **Firmware Revision:** Ver xx.yy **BACnet Protocol Revision:** 7

Product Description:

Delta VFD-CFP2000 is a Variable Frequency AC motor Drive with BACnet embedded.

In VFD-CFP2000, the BACnet connection is by MS/TP, RS485-based. VFD-CFP2000 provides a BACnet communication function that permits it as a server and supports BIBBs defined by the BACnet B-ASC.

VFD-CFP2000 BACnet provides the capability to control and monitor the VFD-CFP2000 machine.

BACnet Standardized Device Profile (Annex L):

- BACnet Operator Workstation (B-OWS)
- BACnet Building Controller (B-BC)
- BACnet Advanced Application Controller (B-AAC)
- BACnet Application Specific Controller (B-ASC)
- BACnet Smart Sensor (B-SS)
- BACnet Smart Actuator (B-SA)

List all BACnet Interoperability Building Blocks Supported (Annex K):

Data Sharing BIBBs

Data Sharing-ReadProperty-B (DS-RP-B)

Data Sharing-WriteProperty-B (DS-WP-B)

Data Sharing-ReadPropertyMultiple-B (DS-RPM-B)

Device and Network Management BIBBs

Device Management-Dynamic Device Binding-B (DM-DDB-B)

Device Management-Dynamic Object Binding-B (DM-DOB-B)

Device Management-DeviceCommunicationControl-B (DM-DCC-B)

Segmentation Capability:

- Segmented requests supported Window Size _____
- Segmented responses supported Window Size _____

Standard Object Types Supported:

Analog Value

Binary Value

Device

Object instantiation is static. Refer to table at end of this document for object details.

Data Link Layer Options:

- BACnet IP, (Annex J)
- BACnet IP, (Annex J), Foreign Device
- ISO 8802-3, Ethernet (Clause 7)
- ANSI/ATA 878.1, 2.5 Mb. ARCNET (Clause 8)
- ANSI/ATA 878.1, RS-485 ARCNET (Clause 8), baud rate(s) _____
- MS/TP master (Clause 9), baud rate(s): 9600, 19200, 38400, 76800
- MS/TP slave (Clause 9), baud rate(s): _____
- Point-To-Point, EIA 232 (Clause 10), baud rate(s): _____
- Point-To-Point, modem, (Clause 10), baud rate(s): _____
- LonTalk, (Clause 11), medium: _____
- Other: _____

Device Address Binding:

Is static device binding supported? (This is currently necessary for two-way communication with MS/TP slaves and certain other devices.) Yes No

Networking Options:

- Router, Clause 6 - List all routing configurations, e.g., ARCNET-Ethernet, Ethernet-MS/TP, etc.
 - Annex H, BACnet Tunneling Router over IP
 - BACnet/IP Broadcast Management Device (BBMD)
- Does the BBMD support registrations by Foreign Devices? Yes No

Character Sets Supported:

Indicating support for multiple character sets does not imply that they can all be supported simultaneously.

- | | | |
|---|---|-------------------------------------|
| <input checked="" type="checkbox"/> ANSI X3.4 | <input type="checkbox"/> IBM™/Microsoft™ DBCS | <input type="checkbox"/> ISO 8859-1 |
| <input type="checkbox"/> ISO 10646 (UCS-2) | <input type="checkbox"/> ISO 10646 (UCS-4) | <input type="checkbox"/> JIS C 6226 |

If this product is a communication gateway, describe the types of non-BACnet equipment/networks(s) that the gateway supports:

The Properties of Objects

Property ID		Object Type		
		Device	Analog Value	Binary Value
#4	ACTIVE TEXT			V
#11	APDU_TIMEOUT	V		
#12	APPLICATION_SOFTWARE_VERSION	V		
#28	DESCRIPTION	V	V	V
#30	DEVICE_ADDRESS_BINDING	V	V	
#36	EVENT STATE		V	V
#44	FIRMWARE_REVISION	V		
#46	INACTIVE TEXT			V
#62	MAX_APDU_LENGTH_ACCEPTED	V		
#63	MAX_INFO_FRAMES	V		
#64	MAX_MASTER	V		
#70	MODEL_NAME	V		
#73	NUMBER_OF_APDU_RETRIES	V		
#75	OBJECT_IDENTIFIER	V *1	V	V
#76	OBJECT_LIST	V		
#77	OBJECT_NAME	V *1	V	V
#79	OBJECT_TYPE	V	V	V
#81	OUT OF SERVICE		V	V
#85	PRESENT VALUE		V *2	V *2
#87	PRIORITY ARRAY		V *3	V *3
#96	PROTOCOL_OBJECT_TYPES_SUPPORTED	V		
#97	PROTOCOL_SERVICES_SUPPORTED	V		
#98	PROTOCOL_VERSION	V		
#104	RELINQUISH DEFAULT		V *3	V *3
#107	SEGMENTATION SUPPORTED	V		
#111	STATUS FLAGS		V	V
#112	SYSTEM_STATUS	V		
#117	UNITS		V	
#120	VENDOR_IDENTIFIER	V		
#121	VENDOR_NAME	V		
#139	PROTOCOL_REVISION	V		
#155	DATABASE_REVISION	V		

***1. The Object_ID and Object_Name Properties of Device are writeable.**

***2. The Present_Value Property of some AV and BV objects are commandable.**

***3. Only Commandable objects support Priority_Array and Relinquish_Default.**

● Commandable Analog Value Object

In VFD-CP2000, we have AV_000~AV_026 supporting commandable Presnet_Value property. In these AV_Objects, we also can use (Multi)Read_Service to access Priority_Array and Relinquish_Default properties.

Object				
Number	R/W	Object Name	Object Description	Unit
AV 000	RW	AV 000 Reserved	Reserved	UNITS NO UNITS
AV 001	RW	AV 001 FreqRefValue	Frequency Reference Value	UNITS HERTZ
AV 002	RW	AV 002 Reserved	Reserved	UNITS NO UNITS
AV 003	RW	AV 003 Reserved	Reserved	UNITS NO UNITS
AV 004	RW	AV 004 Reserved	Reserved	UNITS NO UNITS
AV 005	RW	AV 005 Reserved	Reserved	UNITS NO UNITS
AV 006	RW	AV 006 Reserved	Reserved	UNITS NO UNITS
AV 007	RW	AV 007 Reserved	Reserved	UNITS NO UNITS
AV 008	RW	AV 008 Reserved	Reserved	UNITS NO UNITS
AV 009	RW	AV 009 Reserved	Reserved	UNITS NO UNITS
AV 010	RW	AV 010 Reserved	Reserved	UNITS NO UNITS
AV 011	RW	AV 011 P9-11 map set= ----	AV11 will modify data which is P9-11 mapping to	Depends
AV 012	RW	AV 012 P9-12 map set= ----	AV12 will modify data which is P9-12 mapping to	Depends
AV 013	RW	AV 013 P9-13 map set= ----	AV13 will modify data which is P9-13 mapping to	Depends
AV 014	RW	AV 014 P9-14 map set= ----	AV14 will modify data which is P9-14 mapping to	Depends
AV 015	RW	AV 015 P9-15 map set= ----	AV15 will modify data which is P9-15 mapping to	Depends
AV 016	RW	AV 016 P9-16 map set= ----	AV16 will modify data which is P9-16 mapping to	Depends
AV 017	RW	AV 017 P9-17 map set= ----	AV17 will modify data which is P9-17 mapping to	Depends
AV 018	RW	AV 018 P9-18 map set= ----	AV18 will modify data which is P9-18 mapping to	Depends
AV 019	RW	AV 019 P9-19 map set= ----	AV19 will modify data which is P9-19 mapping to	Depends
AV 020	RW	AV 020 P9-20 map set= ----	AV20 will modify data which is P9-20 mapping to	Depends
AV 021	RW	AV 021 P9-21 map set= ----	AV21 will modify data which is P9-21 mapping to	Depends
AV 022	RW	AV 022 P9-22 map set= ----	AV22 will modify data which is P9-22 mapping to	Depends
AV 023	RW	AV 023 P9-23 map set= ----	AV23 will modify data which is P9-23 mapping to	Depends
AV 024	RW	AV 024 P9-24 map set= ----	AV24 will modify data which is P9-24 mapping to	Depends
AV 025	RW	AV 025 P9-25 map set= ----	AV25 will modify data which is P9-25 mapping to	Depends
AV 026	RW	AV 026 P9-26 map set= ----	AV26 will modify data which is P9-26 mapping to	Depends

● Status (Readonly) Analog Value Object

In VFD-CP2000, we have AV_027~AV_068 with readonly Presnet_Value property. In these AV_Objects, we do NOT have Priority_Array and Relinquish_Default properties.

Object				
Number	R/W	Object Name	Object Description	Unit
AV 027	R	AV 027 Reserved	Reserved	UNITS NO UNITS
AV 028	R	AV 028 Reserved	Reserved	UNITS NO UNITS
AV 029	R	AV 029 Reserved	Reserved	UNITS NO UNITS
AV 030	R	AV 030 Reserved	Reserved	UNITS NO UNITS
AV 031	R	AV 031 Output frequency	Display output frequency(Hz)	UNITS HERTZ

AV 032	R	AV 032 Reserved	Reserved	UNITS NO UNITS
AV 033	R	AV 033 Reserved	Reserved	UNITS NO UNITS
AV 034	R	AV 034 Reserved	Reserved	UNITS NO UNITS
AV 035	R	AV 035 Output torque(%)	Display output torque(%)	UNITS PERCENT
AV 036	R	AV 036 Reserved	Reserved	UNITS NO UNITS
AV 037	R	AV 037 Reserved	Reserved	UNITS NO UNITS
AV 038	R	AV 038 Reserved	Reserved	UNITS NO UNITS
AV 039	R	AV 039 Status word	Display status word,made from BV16~BV31	UNITS NO UNITS
AV 040	R	AV 040 Reserved	Reserved	UNITS NO UNITS
AV 041	R	AV 041 Driver type code	Driver type code	UNITS NO UNITS
AV 042	R	AV 042 Warn code	Warn code	UNITS NO UNITS
AV 043	R	AV 043 Error code	Error code	UNITS NO UNITS
AV 044	R	AV 044 Output current	Display output current(Amp)	UNITS AMPERES
AV 045	R	AV 045 DC-bus voltage	Display DC-BUS voltage(Volt)	UNITS VOLTS
AV 046	R	AV 046 Output Voltage	Display output voltage of U, V, W(Volt)	UNITS VOLTS
AV 047	R	AV 047 Count Value	Display counter value of TRG terminal	UNITS NO UNITS
AV 048	R	AV 048 Power Angle	Display output power angle of U, V, W	UNITS POWER FACTOR
AV 049	R	AV 049 Output Power	Display actual output power of U, V, W(kw)	UNITS KILOWATTS
AV 050	R	AV 050 IGBT temperature	Display the IGBT temperature	UNITS DEGREES CELSIUS
AV 051	R	AV 051 Temperature of driver	Display the temperature of capacitance	UNITS DEGREES CELSIUS
AV 052	R	AV 052 Real carry frequency	Display real carrier frequency of the drive(KHz)	UNITS KILOHERTZ
AV 053	R	AV 053 PID feedback value	Display PID feedback value(%)	UNITS PERCENT
AV 054	R	AV 054 Overload rate	Display overload condition(%)	UNITS PERCENT
AV 055	R	AV 055 Ground fail detect level	Display GND fail detect level(%)	UNITS PERCENT
AV 056	R	AV 056 DC bus ripple	Display DCbus voltage ripples(Volt)	UNITS VOLTS
AV 057	R	AV 057 Fan Speed	Fan speed of the drive(%)	UNITS PERCENT
AV 058	R	AV 058 Output speed(rpm)	Output speed(rpm)	UNITS_REVOLUTIONS_PER_MINUTE
AV 059	R	AV 059 KW per Hour	KW per Hour	UNITS KILOWATTS
AV 060	R	AV 060 Multi-speed switch	Real multi-speed switch	UNITS NO UNITS
AV 061	R	AV 061 AVI input value	0~10V corresponds to 0~100%	UNITS PERCENT
AV 062	R	AV 062 ACI input value	4~20mA/0~10V corresponds to 0~100%	UNITS PERCENT
AV 063	R	AV 063 AUI input value	-10V~10V corresponds to -100~100%	UNITS PERCENT
AV 064	R	AV 064 Digital input status	Refer to P2-12	UNITS NO UNITS
AV 065	R	AV 065 Digital output status	Refer to P2-18	UNITS NO UNITS
AV 066	R	AV 066 CPU pin status of DI	Corresponding CPU pin status of digital input	UNITS NO UNITS
AV 067	R	AV 067 CPU pin status of DO	Corresponding CPU pin status of digital output	UNITS NO UNITS
AV 068	R	AV 068 PLC D1043 value	PLC D1043 value	UNITS NO UNITS

● Commandable Binary Value Object

In VFD-CP2000, we have BV_000~BV_015 supporting commandable Presnet_Value property. In these BV_Objects, we also can use (Multi)Read_Service to access Priority_Array and Relinquish_Default properties.

Object Number	R/W	Object Name	Object Description
BV 000	RW	BV_000_ACTIVE CMD	(0)FreqCmd=0;(1)FreqCmd=FreqRefValue
BV 001	RW	BV_001_FWD/REV CMD	(0)Forward;(1)Reverse
BV 002	RW	BV_002_Reserved	Reserved
BV 003	RW	BV_003_HALT CMD	(0)None;(1)RampDown to 0Hz.
BV 004	RW	BV_004_LOCK CMD	(0)None;(1)OutputFreq stays at current frequency
BV 005	RW	BV_005_Reserved	Reserved
BV 006	RW	BV_006_QSTOP CMD	(0)None;(1)Force driver quick stop
BV 007	RW	BV_007_ServoPower CMD	(0)PowerOff(free run to stop);(1)PowerOn
BV 008	RW	BV_008_Reserved	Reserved
BV 009	RW	BV_009_Reserved	Reserved
BV 010	RW	BV_010_Reserved	Reserved
BV 011	RW	BV_011_Reserved	Reserved
BV 012	RW	BV_012_Reserved	Reserved
BV 013	RW	BV_013_Reserved	Reserved
BV 014	RW	BV_014_Reserved	Reserved
BV 015	RW	BV_015_RESET	RESET:(0)Do nothing;(1)Reset fault

● Status (Readonly) Binary Value Object

In VFD-CP2000, we have BV_016~BV_031 with readonly Presnet_Value property. In these BV_Objects, we do NOT have Priority_Array and Relinquish_Default properties.

Object Number	R/W	Object Name	Object Description
BV 016	R	BV_016_ARRIVE STATE	(0)Not yet;(1)Arrive (OutputFreq=FreqCmd)
BV 017	R	BV_017_FWD/REV STATE	(0)Forward;(1)Reverse
BV 018	R	BV_018_WARN STATE	(0)No Warn;(1)Occur Warn
BV 019	R	BV_019_ERROR STATE	(0)No Error;(1)Occur Error
BV 020	R	BV_020_Reserved	Reserved
BV 021	R	BV_021_Reserved	Reserved
BV 022	R	BV_022_QSTOP STATE	(0)No QSTOP;(1)Occur QSTOP
BV 023	R	BV_023_SerovPower STATE	(0)PowerOff(free run to stop);(1)PowerOn

BV 024	R	BV 024 Reserved	Reserved
BV 025	R	BV 025 Reserved	Reserved
BV 026	R	BV 026 Reserved	Reserved
BV 027	R	BV 027 Reserved	Reserved
BV 028	R	BV 028 Reserved	Reserved
BV 029	R	BV 029 Reserved	Reserved
BV 030	R	BV 030 Reserved	Reserved
BV 031	R	BV 031 Reserved	Reserved